

SAFARI SUKKAH FOLDING INSTRUCTIONS



Remove your Schach
And beams and fold
into one panel



Fold the panel in half



Step on the top of the Sukkah and hold each
loop in each of your hands



Fold the side in your right
hand in first



Then fold the in your left hand
Over the side in your right
hand.



While still holding with your left
hand, release your right hand and
hold the top of the Sukkah



Fold the top in and underneath
your left hand



Your Sukkah is now
folded up.